

Guide to the Fitting Measurements

Bolts protruding from outside flap, including the nuts, must not be wider than 28.75 cms to be able to fit INSIDE Ecoflap recess—otherwise the bolts will need to be recessed. The hole can be larger so long as it is within the flange.

If hole in door is over 7.2 cms and less than 8.3 cms in height, Ecoflap can still work if the cap is fitted and this screw not used.

